

INSTALLATION INSTRUCTIONS AND OPERATION:

UNPACK

Unpack your Elusion® Electronic Cigarette Starter Pack.
Inside you will find:

- 1 x Elusion® Electronic Cigarette Rechargeable Holder Case
- 1 x Battery
- 1 x Charger for Holder Case
- 6 x Standard Atomized Cartridges
- 1 x USB cord
- 1 x Instruction manual



SETUP

STEP 1:

Please charge the Elusion® Battery and Rechargeable Holder Case for 6 hours before use.

STEP 2:

Charging the Elusion® Rechargeable Holder Case:

Plug the USB cord into the wall charger; then plug the Rechargeable Holder Case into the main electricity. A red light will appear when the Rechargeable Holder Case is charging. As soon as it is fully charged, the light will become green or it will turn off.



STEP 3:

Screw the Elusion® battery into the Rechargeable Holder Case. A red light will appear when the battery is charging. As soon as it is charged, the light will become green or it will turn off.



INITIAL USE


STEP 1:

Remove the seals from the cartridge.



STEP 2:

Screw the cartridge onto the battery by rotating clockwise until tight.



STEP 3:

Breathe in on the Elusion® Electronic Cigarette through the inhaler at the end of the cartridge. Upon inhalation, the battery circuit is activated and the indicator at the front of the battery will light up immediately. When inhalation has ceased, the atomization will stop automatically.

During this cycle, the Elusion® E-Cigarette extracts and atomizes the high purity liquid solution from the cartridge. Atomized vapour - with a similar appearance to traditional cigarette smoke - is released in the process. A vapour cloud will appear for several seconds before disappearing.

For best results hold your Elusion® Electronic Cigarette horizontally when inhaling. Do not hold the device upwards or vertically when inhaling as liquid may flow into the mouth causing oral irritation.



Each Elusion® Disposable E-Cigarette cartridge provides up to 300* puffs. Once the cartridge is empty, it can be disposed of.

*Note: The number of puffs per cartridge will vary depending on use.

BATTERY CHARGE

When the available charge from your battery has almost been exhausted, an indicator light on the front of the Elusion® battery will flash 5 consecutive times.

Step 1: Remove the battery from your cartridge and follow step 3 from the setup instructions.



*The Elusion® Battery lasts for up to 300 puffs.

*Note: The number of puffs per battery will vary depending on use.

REPLACING THE CARTRIDGE

When the level of vapour being released from your Elusion® Electronic Cigarette has decreased, it is time to replace the old cartridge. Repeat steps 1 and 2 from the 'Initial Use' section of the installation instructions. Dispose of the old cartridge appropriately.

CAUTIONS:

- Keep out of reach of children.
- Product can become hot. Do not touch the tip of e-cigarette in this instance.
- Do not touch or spill the nicotine liquid contained in the cartridge.
- Do not smoke the Elusion® Electronic Cigarette more frequently or for longer periods than conventional cigarettes.
- Keep away from high temperatures.
- The Elusion® Electronic Cigarette is not a smoking cessation device. Instead, it is a tar-free way to enjoy smoking.

WARNING:

Do not use Elusion® Electronic Cigarettes if you are:
Under the age of 18

Not a smoker
Allergic to any other inhalants
Pregnant or breastfeeding

Always read label and use strictly as directed. If you experience any side-effects, please discontinue use.
PACKAGE DESIGN, TRADEMARK AND ALL COPY